

NOMA⁶

bespeco

Firmware Update Procedure for NOMA6 and NOMA6 White

Please read carefully before starting the process.

Step 1:

After downloading the “NOMA6_firmware_update_x_x_x.zip” file from the official Bespeco website, extract its contents and copy the “NOMA6_firmware_update_x_x_x.MVA” onto an empty USB flash drive.

Step 2:

Make sure no BT devices are paired with NOMA6. Disconnect any cables that may be connected to it and make sure it's at least 50% charged.

Step 3:

Turn off the NOMA6.

Step 4:

Turn on NOMA6 and wait until the blue “BT” LED starts flashing.



Step 5:

Insert the USB flash drive containing the copied file into the appropriate port.

The blue “BT” LED will turn off and the SIGNAL3 LED will turn on.

The firmware update process has started. **DO NOT REMOVE THE USB FLASH DRIVE** until the process is complete, which will be indicated by a sound like “punch” coming from the speaker.

IMPORTANT: The “punch” sound is normal; do not be alarmed.



Step 6:

After hearing the “punch” indicating the end of the process, the SIGNAL3 LED will turn off and the blue “BT” LED will begin flashing again. At this point, turn off NOMA6.

Step 7:

Remove the USB flash drive and turn NOMA6 back on. The firmware update process is complete.